

## **INSTALLATION INSTRUCTIONS**

### **Parts Included**

- 2 Corner Pieces • 1 Front Bar with Grey Inserts •
- 2 #300 Flanges • 8 Wall Screws • 2 Set Screws •

### **Tools Needed**

- Pencil • Drill • Measuring Tape • Hacksaw (Optional) •



1. The bent corner rods and small straight rods attach together with the grey inserts.
2. The flanges attach to the wall (measure for proper distance).
3. The U-Rod assembly fits into the flanges and is secured with set screws.
4. Rods can be adjusted to fit by cutting them with a hacksaw.