

INSTALLATION, OPERATION & MAINTENANCE INSTRUCTIONS

1455 Kleppe Lane ◆Sparks, NV 89431-6467 ◆(775) 359-4712 ◆Fax (775) 359-7424 E-mail: haws@hawsco.com ◆ website: www.hawsco.com

No. 0002076304 (21)

Model 1001/1001HPS Drinking Fountain

NOTE TO INSTALLER: Please leave this information with the Maintenance Department.

LIMITED WARRANTY

HAWS warrants that this specific product is guaranteed against defective material or poor workmanship for a period of one year from date of shipment. HAWS liability under this warranty shall be discharged by furnishing without charge F.O.B. HAWS Factory any goods, or part thereof, which shall appear to the Company upon inspection to be of defective material or not of first class workmanship, provided that claim is made in writing to Haws within a reasonable period after receipt of the product. Where claims for defects are made, the defective part or parts shall be delivered to the Company, prepaid, for inspection. HAWS will not be liable for the cost of repairs, alterations or replacements, or for any expense connected therewith made by the owner or his agents, except upon written authority from HAWS, Sparks, Nevada, HAWS will not be liable for any damages caused by defective materials or poor workmanship, except for replacements, as provided above. Buyer agrees that HAWS shall not be liable for general, special, or consequential damages claimed to arise under the contract of sale. The drinking fountain manufactured by HAWS is warranted to function if installation and maintenance instructions provided are adhered to. The units also must be used for the purpose for which they were intended.

NO OTHER WARRANTIES EXPRESSED OR IMPLIED ARE AUTHORIZED, PROVIDED OR GIVEN BY HAWS.

SHOULD YOU EXPERIENCE DIFFICULTY WITH THE INSTALLATION OF THIS MODEL PLEASE CALL:

TECHNICAL SUPPORT: 1-800-766-5612

FOR CUSTOMER SERVICE: 1-888-640-4297

03/20 Model 1001/1001HPS Page 1 of 5

RECOMMENDED TOOLS: Hack saw, pipe joint sealant, screwdriver, level, 12" adjustable wrench, 10" pipe wrench, 3/32" and 5/32" hex key wrench, 9/16", 1/2", 7/16" socket wrench or open-end wrench.

LOCATION OF UNIT: The Model 1001/1001HPS Drinking Fountain is a wheelchair accessible drinking water facility. The height dimensions shown, meet current ADA requirements. When installing this unit, local, state or federal codes should be adhered to. If height other than shown is required, then dimensions must be adjusted accordingly.

SUPPLY LINE: The minimum recommended line size is 1/2" IPS with 30-90 PSI (2-6 ATM) flowing pressure. Where sediment or mineral content is a problem, an inlet filter is recommended.

PLUMBING CONNECTIONS: Inlet is 3/8" O.D. push-in type fitting. Waste outlet is 1-1/4" O.D. tube.

MAINTENANCE: Periodically clean the strainer. Refer to 5874 Series Valve Manual for more information.

GENERAL NOTES:


- For all plastic push-in type fitting connections, only connect NSF-61 copper or plastic tubing. Stainless steel or glass tubing is not recommended. The following assembly instructions must be followed to ensure a watertight connection:
 - a. Cut tubing square and clean.
 - b. Mark from end of tube the length of insertion (See table below).
 - c. Push tube into the fitting until it bottoms out.
 - d. To remove, depress collet and pull tubing out.

Tube Sizes	O.D. Tolerance	Insertion Depth
1/4"	±.005"	11/16"
3/8"	±.005"	3/4"
1/2"	±.005"	7/8"

TROUBLESHOOTING			
PROBLEM		REPAIR CHECKLIST	
Insufficient bubbler flow.	1a.	Check that inlet screwdriver stop valve is in wide- open position.	
	b.	Verify minimum 30 psi flowing supply pressure.	
	C.	Clean strainer. See 5874 Series Valve Manual.	
	d.	Adjust valve to increase flow. Use front adjust screw or see 5874 Series Valve Manual.	
	e.	Clean screens (inside nozzle body). Unscrew nozzle insert and very gently activate water supply to pop out qty. 3 screens (be careful not to lose screens). Remove any debris clogging the screen openings and place back into nozzle body. Reassemble nozzle insert.	

For more information about Haws products, see our website: www.hawsco.com

03/20 Model 1001/1001HPS Page 3 of 5



PARTS BREAKDOWN

ECN NO REVISED PERIBY IMADEL (S)

1455 KLEPPE LANE SPARKS, NEVADA 89431 (775) 359-4712 FAX (775) 359-7424 E-MAIL: HAWS@HAWSCO.COM WEBSITE: WWW.HAWSCO.COM

WEBSITE: WWW.HAWSCO.COM
PART NUMBER
0002076304

WHEN ORDERING PARTS PLEASE SPECIFY MODEL NUMBER.

NNO. REVISED PER BY
ECN: 5527 FV
WIND DATE CHKD
TOWN DATE

10/1998 DP

10/1998 DP

PAGE 4 OF 5

DIMENSIONS (LOCATIONS), WASTE AND SUPPLY REQUIREMENTS

CODES SHOULD BE ADHERED TO FOR INSTALLATION

3 INSTALLER MUST PROVIDE TRAP FOR PROPER INSTALLATION.

REMOVE VALVE FROM PUSH BUTTON TO INSTALL WASTE

REINSTALL VALVE AND ADJUST FLOW.

ELBOW ONTO BOWL. AFTER WASTE ELBOW IS INSTALLED,

REFER TO 5874 SERIES OPERATION AND MAINTENANCE MANUAL

WASTE BEND 3


OPTIONAL TRAP ACCESS PANEL


MODELS 6603 AND 6603HPS

FOR PUSH BUTTON AND VALVE INSTALLATION/MAINTENANCE

OTHER THAN SHOWN.

INSTRUCTIONS.







Ю

2

PAGE

SECTION A-A ROTATED 90° INTO VIEW BRACKET MOUNTING DETAIL





6700 MOUNTING PLATE
MUST BE INSTALLED BEFORE FINISH WORK
THIS PLATE IS REQUIRED - SOLD SEPARATELY.



1455 KLEPPE LANE SPARKS, NEVADA 89431 (775) 359-4712 FAX (775) 359-7424 E-MAIL: HAWS@HAWSCO.COM WEBSITE: WWW.HAWSCO.COM

ECN NO. REVISED PER BY: ECN: 5527 FV
DRAWN: DATE: CHKO: RTM (05/97 DP)

| CONTROL | CHKO: DP | CHKO: CHKO: RTM (05/97 DP) | CHKO: RTM (05

PART NUMBER 0002076304.D REVISION 21