


NARROW WALL WARM CLIMATE HYDRANT



BOX TYPE WITH CONCEALED HOSE CONNECTION

FUNCTION: For installation in interior or exterior wall of building where a concealed hose connection is desired and there is no danger of freezing. Hydrant features an integral type vacuum breaker. The locking cover prevents unauthorized use.

The hydrant contained within the box assembly is the 5618 Warm Climate Hydrant which complies with the Lead Free Plumbing Law. Certified by the IAPMO R & T, File No. 6127 (NSF/ANSI 372)



FRONT VIEW
with COVER OPEN



FRONT VIEW

16 Gauge Frame and -
Hinged Locking Cover
(Cover opens full 180°)

A small amount of water seepage may occur from the vacuum breaker and operating screw upon initial opening and closing of the hydrant. This is normal operation.

NOTES:

1. Recommended wall opening is 3 3/16 (83) x 8 1/2 (215).
2. Add 3/8 (10) when optional box face material is specified.
3. All Jay R. Smith hydrants are manufactured with "NO LEAD" brazing rings and USDA approved lubricants.
4. Dimensions shown in parentheses are in millimeters.
5. The AB1953, California Lead Law, and NSF/ANSI Standard 61-2008 - Drinking Water System Components are not applicable to Jay R. Smith hydrants as they do not convey/dispense water for human consumption through drinking or cooking.
6. **FOR IRRIGATION PURPOSES ONLY.**

REGULARLY FURNISHED:

All Bronze Warm Climate Hydrant with Chrome Plated Face, Hose Connection having Integral ASSE 1011 Vacuum Breaker, 360 Swivel Inlet Connection, "T" Handle Key and Stainless Steel Box.

VARIATIONS:



- ☐ Cylinder Lock -CL

OPTIONAL MATERIALS:

- | | |
|--------------------------|------------------------------|
| <input type="checkbox"/> | Polished Bronze Box Face -PB |
| <input type="checkbox"/> | Nickel Bronze Box Face -NB |
| <input type="checkbox"/> | Rough Bronze Box Face -RB |
| <input type="checkbox"/> | Chrome Plated Box Face -CP |

Installer is responsible for providing a 100% watertight positive seal at the hydrant to box interface and hydrant to wall interface. Seal all interior joints, seams, gasket seams/closures including around the hydrant box flange with an appropriate sealant recommended by a sealant manufacturer. NOTE: Jay R. Smith does not warrant the performance or life expectancy of the sealant material.

E	7-20-16	Added Note	TBW	BW	WEIGHT POUNDS	VOLUME CUBIC FEET	FIGURE NUMBER 5518
D	6-17-16	Added Note	TBW	TWK			
C	1-31-13	Revised Notes	TBW	CL			
B	1-7-11	Revised Regularly Furnished	TBW RN	CL CL			
REV.	DATE	DESCRIPTION	BY	CKD. BY			

B	<div style="display: flex; align-items: center;"> <div style="flex: 1;"> <p>JAY R. SMITH MFG. CO. <small>MEMBER OF MORRIS GROUP INTERNATIONAL POST OFFICE BOX 3237 MONTGOMERY, ALABAMA 36109-0237 (USA) TEL: 334-277-8520 FAX: 334-272-7396 www.jrsmith.com</small></p> </div> <div style="flex: 1; text-align: center;"> <p>MEMBER OF:</p> </div> <div style="flex: 1; text-align: center;"> <p>MEMBER OF:</p> </div> <div style="flex: 1; text-align: center;"> <p>MEMBER OF:</p> </div> </div>					LOCATION 																											
	<h2 style="margin: 0;">PARTS LIST WITH MAINTENANCE INSTRUCTIONS</h2>																																
DRAWING NUMBER S5518BS	SIZE A	SCALE: NONE	DATE: 08/26/09	APPROVED BY: CL	CHECKED BY: CL	DRAWN BY: JJ	DIMENSIONS ARE SUBJECT TO MANUFACTURERS TOLERANCE AND CHANGE WITHOUT NOTICE	<div style="text-align: center;">  <p style="margin-top: 10px;">▲▲ THESE REPLACEMENT PARTS AVAILABLE IN HPRK-18VB</p>  <p style="margin-top: 10px;">▲ THESE REPLACEMENT PARTS AVAILABLE IN HPRK-18</p> </div> <div style="margin-top: 20px;"> <p>MAINTENANCE INSTRUCTIONS:</p> <ol style="list-style-type: none"> 1. Shut off water supply. 2. Remove face nut. 3. Pull stem out for complete access to all working parts. 4. Check all working parts for replacement. 5. Replace complete stem assembly and face nut. <p style="margin-top: 20px;">* These Parts are accessible from face of hydrant by removing face nut.</p> </div> <div style="margin-top: 20px; border: 1px solid black; padding: 5px; font-size: small;"> <p>HYDRANT PARTS LIST</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>No.</th> <th>Description</th> <th>No.</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Head/Casing Assembly</td> <td>10a</td> <td>Coupling</td> </tr> <tr> <td>3</td> <td>Key</td> <td>11</td> <td>Washer Screw</td> </tr> <tr> <td>7</td> <td>Face Nut</td> <td>14</td> <td>Vacuum Breaker</td> </tr> <tr> <td>8</td> <td>Operating Screw</td> <td>18</td> <td>Plunger Washer</td> </tr> <tr> <td>9</td> <td>Operating Screw "O" Ring</td> <td></td> <td></td> </tr> </tbody> </table> </div> <div style="margin-top: 20px; border: 1px solid black; padding: 5px; font-size: x-small;"> <p>Installer is responsible for providing a 100% watertight positive seal at the hydrant to box interface and hydrant to wall interface. Seal all interior joints, seams, gasket seams/closures including around the hydrant box flange with an appropriate sealant recommended by a sealant manufacturer. NOTE: Jay R. Smith does not warrant the performance or life expectancy of the sealant material.</p> </div>		No.	Description	No.	Description	1	Head/Casing Assembly	10a	Coupling	3	Key	11	Washer Screw	7	Face Nut	14	Vacuum Breaker	8	Operating Screw	18	Plunger Washer	9	Operating Screw "O" Ring		
No.	Description	No.	Description																														
1	Head/Casing Assembly	10a	Coupling																														
3	Key	11	Washer Screw																														
7	Face Nut	14	Vacuum Breaker																														
8	Operating Screw	18	Plunger Washer																														
9	Operating Screw "O" Ring																																
5518BS	FIGURE NUMBER	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">REV.</td> <td style="width: 15%;">DATE</td> <td style="width: 30%;">DESCRIPTION</td> <td style="width: 15%;">BY</td> <td style="width: 15%;">CKD. BY</td> </tr> <tr> <td style="text-align: center;">B</td> <td style="text-align: center;">7-20-16</td> <td rowspan="2">Added Note Rev. Replacement Parts</td> <td style="text-align: center;">TBW</td> <td style="text-align: center;">BW</td> </tr> <tr> <td style="text-align: center;">A</td> <td style="text-align: center;">12-3-12</td> <td style="text-align: center;">TBW</td> <td style="text-align: center;">CL</td> </tr> </table>		REV.	DATE	DESCRIPTION	BY	CKD. BY	B	7-20-16	Added Note Rev. Replacement Parts	TBW	BW	A	12-3-12	TBW	CL	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">WEIGHT POUNDS</td> <td style="width: 20%;">VOLUME CUBIC FEET</td> <td style="width: 60%;">FIGURE NUMBER</td> </tr> <tr> <td style="height: 40px;"></td> <td></td> <td style="text-align: center; font-size: 2em;">5518BS</td> </tr> </table>	WEIGHT POUNDS	VOLUME CUBIC FEET	FIGURE NUMBER			5518BS									
REV.	DATE	DESCRIPTION	BY	CKD. BY																													
B	7-20-16	Added Note Rev. Replacement Parts	TBW	BW																													
A	12-3-12		TBW	CL																													
WEIGHT POUNDS	VOLUME CUBIC FEET	FIGURE NUMBER																															
		5518BS																															



WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov